

# Expion360 Boondocker Wiring Diagram

12.8V e360 LiFePO4 Battery Bank | Internal BMS | 3kVA Inverter/Charger  
 Expandable Solar + Alternator Charging | Advanced Monitoring and Control


Download PDF and zoom in for details.



KEY	
VE. Direct	
RJ45	
USB/HDMI	
Ground	
Case Ground	
Chassis Ground	



Download the VictronConnect App for Bluetooth capabilities.



Note: This diagram is for training purposes only. Always follow manufacturer recommendations for battery bank sizing, and ensure solar array is properly sized based on system design considerations.